Stylesheet Version v1.1.1

Description

RETICLE TRANSFERRING SUPPORT AND TRANSFERRING METHOD THEREOF

BACKGROUND OF INVENTION

[0001] 1. Field of the Invention

[0002] The present invention provides a reticle transferring support for containing a reticle, and more particularly to a reticle transferring support that can avoid damaging the reticle.

[0003] 2. Description of the Prior Art

[0004] Photolithography is an important step in the entire processes of semiconductor production. Characteristics associated with MOS transistors, such as film pattern or dopant region, are determined by this step. Photolithography basically proceeds by covering a layer of photo-sensitive material on a semiconductor, and casting a parallel light beam, through a reticle, onto the photosensitive material. Since the reticle has patterns of a circuit layout, the photo-sensitive material incurs a selective photo reaction so that the pattern on the reticle will be transferred to the semiconductor wafer.

[0005]

In general, the reticle comprises a smooth and transparent plate of

glass or quartz as its foundation, and a layer of chromium film of 1000Ã thick over the surface of the reticle. Therefore the pattern on the reticle is very fragile. For protecting the pattern of the reticle, the reticle is generally placed in a SMIF (standard mechanical interface) pod, and carried to an exposure apparatus by a robot arm to avoid damaging the reticle.

[0006] Please refer to Fig.1 and Fig.2. Fig.1 is a top view of a reticle transferring support of a SMIF pod in the prior art. Fig.2 is a cross-section diagram of a reticle transferring support of a SMIF pod in the prior art. As shown in Fig.1, the reticle transferring support 10 comprises a supporting base 12 having four rectangular braces 14 for supporting a reticle 16. For conforming to the semiconductor and material international (SEMI) standard, both sides of the reticle transferring support have to keep a gap of 0.95mm for the convenience of reticle load/unload. However, it is not easy to fix the position of the reticle when the operator places the reticle 16 with a reticle clip into the reticle transferring support 10. Particularly, if the position of the reticle 16 deviates too much, errors could happen in the following vacuum adsorption operation.

[0007]

Therefore the operator needs to adjust the reticle 16 to proper position. However, it is not easy to adjust the position of the reticle 16 manually, besides, damages of the reticle 16 are often caused by friction during the reticle adjusting action. As shown in Fig.2, the braces 14 of the reticle transferring support 10 have a rectangular structure, thus the

APP ID=10604092 Page 2 of 18

contact area between the reticle 16 and the braces 14 is wide, which makes it easy to damage a bar code area (not shown) and a vacuum adsorption area (not shown) of the reticle 16.

- [0008] Please refer to Fig.3. Fig.3 is a flow chart of a reticle transferring procedure according to the prior art. As shown in Fig.3, the reticle transferring procedure comprises following steps:Step 30: start;Step utilize an opener to open a SMIF pod;Step 34: utilize a reticle clip to place a reticle into a reticle transferring support of the SMIF pod;Step 36: adjust the position of the reticle;Step 38: utilize the opener to close the SMIF pod; andStep 40: end.
- [0009] In the reticle transferring procedure of the prior art, first an opener as Asyst ALU opener) is employed to open a SMIF pod. Then a reticle is manually placed in a reticle transferring support of the SMIF pod by a reticle clip, and adjusted to proper position. Finally, the SMIF pod is closed by the opener. As mentioned above, the reticle transferring support 10 of the SMIF pod has to keep a gap of 0.95mm on both sides for conforming to the SEMI standard, and moreover the contact area between the reticle 16 and the rectangular braces 14 is too wide, thus the back surface of the reticle 16 is easily damaged. For this reason, a reticle transferring support that can avoid damaging the reticle is eagerly required.

SUMMARY OF INVENTION

[0010] It is therefore a primary objective of the claimed invention to provide a reticle transferring support to solve the reticle damage and position

APP ID=10604092 Page 3 of 18

deviation problems of the prior art reticle transferring support.

- [0011] According to the claimed invention, a reticle transferring support that can fix the position reticle and avoid reticle damages is provided. The reticle transferring support can further work in coordination with a reticle stocker to load a reticle into a SMIF (standard mechanical interface) pod, such that the reticle damages and other problems caused by humans will be avoided. The reticle transferring support of the present invention comprises a supporting base for containing a reticle, a plurality of braces for supporting the reticle, and a plurality of holders fixing the reticle position. It is worth noticing that the inner part of the holders is an inclined plane or a curved surface, such that the reticle can be effectively fixed.
- [0012] It is an advantage of the claimed invention that the inner part of the holders is inclined, thus the reticle is automatically fixed as long as the reticle is placed in the reticle transferring support. Moreover, the operator does not need to adjust the reticle position, so the reticle will not be damaged by friction. In addition, the reticle transferring support of the present invention can further work in coordination with a robot arm of a reticle stocker to load the reticle into a SMIF pod.
- [0013] These and other objectives of the present invention will no doubt become obvious to those of ordinary skill in the art after having read the following detailed description of the preferred embodiment that is illustrated in the various figures and drawings.

BRIEF DESCRIPTION OF DRAWINGS

APP ID=10604092 Page 4 of 18

- [0014] Fig.1 is a top view of a reticle transferring support of a SMIF pod in the prior art.
- [0015] Fig.2 is a cross-section diagram of a reticle transferring support of a SMIF pod in the prior art.
- [0016] Fig.3 is a flow chart of a reticle transferring procedure according to the prior art.
- [0017] Fig.4 is a top view of a reticle transferring support of the present invention.
- [0018] Fig.5 is a cross-section diagram of a reticle transferring support of the present invention.
- [0019] Fig.6 is a flow chart of a reticle transferring procedure according to the present invention.

DETAILED DESCRIPTION

[0020] Please refer to Fig.4 and Fig.5. Fig.4 a top view of a reticle transferring support of the present invention, and Fig.5 is a cross-section diagram of a reticle transferring support of the present invention. As shown in Fig.4 and Fig.5, the reticle transferring support 50 of the present invention comprises a supporting base 52 for containing a reticle 58, a plurality of braces 54 for supporting the reticle 58, and a plurality of holders 56 for fixing the reticle position. It is worth noticing that the braces 54 installed on the supporting base 52 are spheroidic structures such that the contact area between the reticle 58 and the braces 54 is smaller. In addition, the braces 54 are adjustable to prevent from damaging a bar

APP ID=10604092 Page 5 of 18

code area (not shown) and a vacuum adsorption area (not shown). The braces 54 include a soft material, such as plastic or other flexible materials, to avoid scraping the reticle 58. In addition, because the inner part of the holders 56 is an inclined plane or a curved surface, the holders 56 will automatically fix the reticle 58 to a proper position.

[0021] Please refer to Fig.6. Fig.6 is a flow chart of a reticle transferring procedure according to the present invention. As shown in Fig.6, the reticle transferring procedure includes following steps:

[0022] Step 100: start;

[0023] Step 102: place a reticle transferring support and a SMIF pod on a load port of a reticle stocker;

[0024] Step 104: utilize a reticle clip to place a reticle in the reticle transferring support;

[0025] Step 106: open the SMIF pod;

[0026] Step 108: utilize a robot arm of the reticle stocker to take out the reticle;

[0027] Step 110: utilize the robot arm to place the reticle in the SMIF pod;

[0028] Step 112: close the SMIF pod; and

[0029] Step 114: end.

[0030] In the reticle transferring procedure according to the present invention, a reticle transferring support is employed in coordination with a reticle stocker to accomplish the reticle transferring operation. In the above-

APP_ID=10604092 Page 6 of 18

mentioned reticle transferring procedure, first the reticle transferring support and the SMIF pod are placed on the load port of the reticle stocker. It is worth noticing that the original function of the reticle stocker is to stock the reticle, the reticle stocker is used to carry the reticle in the present invention since the reticle stocker has a robot arm. Then the reticle is placed in the reticle transferring support of the present invention by manually using a reticle clip. As long as the reticle is placed in the reticle transferring support, the reticle will be automatically fixed because of the inclined-plane design of the holders. Furthermore, the braces are plastic spheroidic structure such that the reticle will not be scraped or damaged. Finally, the SMIF pod is opened by an opener, the reticle is carried from the reticle transferring support to the SMIF pod by the robot arm, and the SMIF pod is closed by the opener.

[0031] According to the reticle transferring procedure of the prior art, the reticle is directly placed in the SMIF pod by manually using a reticle clip. The operator needs to adjust the reticle to proper position. However, the reticle is easily damaged or scraped by friction during the adjusting action.

[0032]

In contrast with the prior art, the present invention utilizes a reticle transferring support as a transferring interface. The inclined-plane design of the holders allows the reticle to be fixed automatically, and the soft spheroidic structure of the braces prevents the reticle from being damaged when the reticle is placed in the reticle transferring

APP ID=10604092 Page 7 of 18

support. Afterward, the reticle can be precisely placed in the SMIF pod with the robot arm of the reticle stocker.

[0033] Those skilled in the art will readily observe that numerous modifications and alterations of the device may be made while retaining the teachings of the invention. Accordingly, the above disclosure should be construed as limited only by the metes and bounds of the appended claims.

APP_ID=10604092 Page 8 of 18